

INSTALLATION OF CAPTIVE FASTENER CFS2, CFR2,CFN2

- Punch or drill correct size mounting hole in sheet material. Do not deburr or perform any secondary operations.
- Place pilot end of nut into mounting hole, preferably entering the punched side.
- With punch and anvil surfaces parallel, apply squeezing force until the shoulder of the retainer or nut comes in contact with the sheet material. For type CFN10, squeeze until the retainer is flush in the sheet.

