

- Punch or drill properly sized round mounting hole in board.
- Place fastener into mounting hole as shown below.
- With punch and anvil surfaces parallel, apply squeezing force until shoulder or head contacts the board.

