

- Punch or drill properly sized round mounting hole in panel.
- Place fastener into mounting hole as shown below.
- With punch and anvil surfaces parallel, apply only enough squeezing force to embed the head flush with the panel.

