

- Punch or drill properly sized mounting hole in board.
- Place fastener into mounting hole.
- With punch and anvil surfaces parallel, apply squeezing force until shoulder contacts the board.

