

- Punch or drill properly sized round mounting hole in sheet. Do not perform any secondary operations such as deburring.
- Place shank of fastener into mounting hole, preferably the punch side.
- With punch and anvil surfaces parallel, apply squeezing force until shoulder of the retainer or nut comes in contact with the sheet material.

