

- Punch or drill properly sized mounting hole in panel.
- Place the barrel of the fastener into the mounting hole, preferably the punch side.
- With the punch and anvil surfaces parallel, apply only enough squeezing force to embed the head flush with the panel.

